

Инкубаторы IB4-03AV, 05AV, 10AV, 15AV

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

эл.почта: jhc@nt-rt.ru || сайт: <http://jeiotech.nt-rt.ru/>

Incubator, Air-jacket (Advanced, IB4-AV)

An air-jacket type of incubator, advanced type

Model Name : IB4-03AV, 05AV, 10AV, 15AV



Model		IB4-03AV	IB4-05AV	IB4-10AV	IB4-15AV
Chamber volume (L / cu ft)		25 / 0.88	60 / 2.19	114 / 4.03	150 / 5.30
Temperature	Range (°C / °F)	Amb. +5 to 80 / Amb. +9 to 176			
	Fluctuation at 37°C (±°C / °F)	0.10 / 0.18	0.10 / 0.18	0.15 / 0.27	0.10 / 0.18
	Variation at 37°C (±°C / °F)	0.31 / 0.56	0.48 / 0.86	0.46 / 0.83	0.55 / 0.99
	Heating time to 37°C (min.) ¹⁾	44	40	46	49
	Recovery time at 37°C (min.)	5	9	9	9

Control panel		5 inch TFT Color LCD			
Communication interface		USB-B, RS-232			
Function	Recently event record	36 ea			
	Recommended temperature	Suggest three frequently used temperature			
	Graph	Available viewing stored and real-time graphs			
	Data storage	Save your experiment data (in CSV format)			
	Temp. ramping rate (°C/min. °F/min)	0 to 2.0 0 to 3.6			
Dimension (W×D×H)	Interior (W x D x H, mm / inch)	300 x 210 x 400 /11.81 x 8.27 x 15.75	380 x 330 x 480 /14.96 x 12.99 x 18.9	485 x 350 x 655 / 19.1 x 13.78 x 25.79	550 x 376 x 710 / 21.62 x 14.8 x 27.95
	Exterior (W x D x H, mm / inch)	478 x 527 x 604 / 18.8 x 20.75 x 23.78	558 x 648 x 684 / 21.97 x 25.5 x 26.93	663 x 677 x 859 / 26.1 x 26.65 x 33.82	728 x 704 x 914 / 28.66 x 27.7 x 36.0
	Net weight (Kg / lbs)	31 / 68.34	40 / 88.18	55 / 121.25	60 / 132.28
Shelves	Quantity of shelves (standard/max.)	2 / 4	2 / 5	2 / 8	2 / 9
	Max. Load per shelf (Kg / lbs)	20 / 44.09	20 / 44.09	20 / 44.09	20 / 44.09

Electrical requirements (230V, 50 / 60Hz, A)	2.5	3.5	3.5	3.5
Cat. No.	AAH21755K	AAH21765K	AAH21775K	AAH21785K
Electrical requirements (120V, 60 Hz, A)	4.8	6.7	6.7	6.7
Cat. No.	AAH21753U	AAH21763U	AAH21773U	AAH21783U

※ Technical data according to DIN 12880



По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47